FENDER "BASS-MAN" LAYOUT

MODEL 5E6-A

A-EE

NOTICE

VOLTAGES READ TO GROUND WITH ELECTRONIC VOLTMETER. VALUES SHOWN + OR − 20 %